



Get with the Program! DBA table programming, briefly explained

- 1) Open the DBA coin door, and press and hold the “Access” as shown at the left.
- 2) The display will count down , in sequence: 5, 4, 3, 2, 1, SET UP.
- 3) Release the access button. You may now use the two buttons on the coin door to set your programming.

The **TIME/RACK** button moves to the next value to be set.

The **START** button will allow you to scroll through the range of parameters for that value.

To exit programming at any time, press the “Access” button once, and then the **TIME/RACK** button on the door.



ACCESS BUTTON






Get with the Program! DBA table programming, briefly explained

Now that you are in programming mode,
the basics are to set the day & time, and your Normal Game Price.

Parameter 1—Set Clock DAY (Sun—Sat)
Parameter 2—Set Clock HOUR (military time: 00—23)
Parameter 3—Set Clock MINUTE (00—59)
(the clock doesn't start until you exit programming mode, so set it a few minutes ahead)
Parameter 4—Normal Game Cost (\$0.00—\$10.00)

To exit programming at any time, press the
“Access” button once, and then the TIME/
RACK button on the door.





Get with the Program! DBA table programming, briefly explained

Additional programming will help you take advantages of the Happy Hour and Bonus pricing features

It would be helpful to get copies of the Programming Templates, available in the owners' manual, and downloadable from www.valley-dynamo.com/parts

Parameter 5 & 6—Happy Hour 1 & 2 Game Cost (\$0.00—\$10.00)

Parameter 7 & 8—Time play Game Cost (\$0.00—\$10.00) and interval

Parameter 9-12—Credit Bonus

(to offer additional credit for using larger bills. Examples: 6 games for \$5.00, 13 games for \$10.00)

Parameter 13—Time Bonus (extra minutes for purchasing 1 hour of play)

Parameter 14-69—Time/Date settings for Happy Hours

To exit programming at any time, press the "Access" button once, and then the TIME/RACK button on the door.

